# Soft Starter Three-Phase Scroll Compressor Soft Starter Types RSBD, RSBT

### CARLO GAVAZZI



## **Product Description**

RSBD and RSBT are easy to use soft starters for scroll compressors up to 45Amp (RSBD) and 32Amp (RSBT) nominal current. The units are equipped with a patented auto-adaptive algorithm that automatically adapts itself to the specific compressor it is controlling ensuring that an optimum inrush current reduction is achieved.

Type Selection

RSBD is a 2-phase controlled solution and RSBT is a 3phase controlled solution. RSBD and RSBT are internally bypassed resulting in less heat dissipation inside the panel.

Short Circuit and Overload protection are not provided with the controller and must be procured separately.

- Soft starting of 3-phase scroll compressors up to 45Amp
- Patented auto-adaptive algorithm for optimum inrush current reduction (No user settings required)
- 2- (RSBD) and 3-Phase (RSBT) controlled solutions
- Current balancing strategy (RSBD models)
- Integrated bypass relays
- Internally supplied
- Short ramp up time: <600ms
- Rated operational voltage: 220VAC, 400VACrms, 50/60Hz
- Rated operational current: 12<sup>1</sup>, 16, 25, 32, 37<sup>1</sup>, 45<sup>1</sup> AAC
- Over-temperature, Overcurrent, Locked Rotor protection
- cULus, CE, RoHS compliant, CCC<sup>1</sup>
- HP version for multi-compressor systems
- VDE approved (Up to 32AAC) for RSBT...HPV models Note: Other models (RSBT) only VDE approved up to 15Arms

### Ordering Key RSB T 40 16 E V 11 H P V

Compressor Soft Starter — Controlled Phases — Operational Voltage — Rated Operational Current — Control Voltage —
Version
Optimised algorithm for multi-compressor systems and high pressure starts
VDE approved versions (up to 32Arms) <sup>2</sup>

Options

**Rated Operational Operational Voltage Ue** Type **Control Voltage Uc** Version Current le @ 40°C RSBD 40: 220 - 400 VAC 12: 12 Arms<sup>1</sup> E: 110 - 400 VAC V11: DIN Mount2 DIN Mount & RFPMV00 module ready mounted<sup>2</sup> 2-Controlled +10% -15% 16: 16 Arms +10% -15% V21: phases 25: 25 Arms V51 DIN Mount (UL approved)<sup>2</sup> 32: 32 Arms F1: 24VAC/DC V61: DIN Mount & RFPMV00 module ready mounted 37: 37 Arms1 +10% -15% (UL approved)2 V HP Optimised algorithm for multi-compressor 50: 45 Arms<sup>1</sup> systems & high pressure starts V.HPV: VDE approved (up to 32AAC) 22: 220VAC, +10% -15% RSBT 3-Controlled 40: 400VAC, +10% -15% phases Versions Operational Control HP Algorithm **VDE** Approved Operational Туре Voltage (up to 32Arms) Current Voltage 12 16 25 V51 E [RSBD] [40] ΗP 32 37 50 V11 [22] V61 16 [RSBT] [40] 25 ΗP v 32 V11 V21

> V51 V61

<sup>1</sup> Applies to RSBD40 models only

<sup>2</sup> Applies to RSBT.. HPV models only



# Selection Guide: RSBD (2-phase controlled)

Control	Version	Rated Operational Current					
Voltage		12 Arms	16 Arms	25 Arms	32 Arms	37 Arms	45 Arms
110 – 400 VAC	V51HP	RSBD4012EV51HP RSBD4012EV61HP	RSBD4016EV51HP RSBD4016EV61HP	RSBD4025EV51HP RSBD4025EV61HP	RSBD4032EV51HP RSBD4032EV61HP	RSBD4037EV51HP RSBD4037EV61HP	RSBD4050EV51HP RSBD4050EV61HP
24VAC/DC	V61HP	RSBD4012FV51HP RSBD4012FV61HP	RSBD4016FV51HP RSBD4016FV61HP	RSBD4025FV51HP RSBD4025FV61HP	RSBD4032FV51HP RSBD4032FV61HP	RSBD4037FV51HP RSBD4037FV61HP	RSBD4050FV51HP RSBD4050FV61HP

# Selection Guide: RSBT (3-Phase Controlled)

Operational Voltage	Approvals	Version	Rated Operational Current		
			16 Arms	25 Arms	32 Arms
220 VAC			RSBT2216EV11HP	RSBT2225EV11HP	RSBT2232EV11HP
400 VAC	CE	V11/V11HP V21HP	RSBT4016EV11 RSBT4016EV11HP RSBT4016EV21HP	RSBT4025EV11 RSBT4025EV11HP RSBT4025EV21HP	RSBT4032EV11 RSBT4032EV11HP RSBT4032EV21HP
220 VAC	CE,	V51HP	RSBT2216EV61HP	RSBT2225EV61HP	RSBT2232EV61HP
400 VAC	cULus	,	RSBT4016EV51HP RSBT4016EV61HP	RSBT4025EV51HP RSBT4025EV61HP	RSBT4032EV51HP RSBT4032EV61HP
220 VAC		V11/V11HP	RSBT2216EV11HPV	RSBT2225EV11HPV	RSBT2232EV11HPV
400 VAC		V1/V11HP V21HP	RSBT4016EV11HPV RSBT4016EV21HPV	RSBT4025EV11HPV RSBT4025EV21HPV	RSBT4032EV11HPV RSBT4032EV21HPV
220 VAC	CE, V51HP cULus V61HP	V51HP	RSBT2216EV61HPV	RSBT2225EV61HPV	RSBT2232EV61HPV
400 VAC			RSBT4016EV51HPV RSBT4016EV61HPV	RSBT4025EV51HPV RSBT4025EV61HPV	RSBT4032EV51HPV RSBT4032EV61HPV

## **General Specifications**

Starting Method	Current limit, auto-adaptive	Status Indication LEDs	
Ramp-up time	< 600 msec	Power Supply ON	Green LED
Ramp-down time	0 sec	Recovery Mode	
Initial Torque	Initial torque will vary indirectly through the variation of the current limit through the auto- adaptive algorithm	(alarm condition) Alarm Special alarm <sup>3</sup>	Flashing Red LED Red LED Green LED OFF and Red LED ON
Undervoltage/Overvoltage		Form Designation	1
protection		Vibration	Acc. To IEC60068-2-26
Recovery from Undervoltage			
RSBD40	174 VAC	Frequency 1	2 [+3/-0]Hz to 25Hz
RSBT22	190 VAC		Displacement +/- 1.6mm
RSBT40	330 VAC	Frequency 2	Acc. To IEC60068-2-26
Recovery from Overvoltage			25Hz to 100Hz @ 2g
RSBD40	470 VAC		(19.96m/s <sup>2</sup> )
RSBT22	250 VAC		
RSBT40	470 VAC		

<sup>1</sup> Applies to RSBD models only <sup>2</sup> Applies to RSBT models only <sup>3</sup> Applies to RSBT...HPV models only

### **CARLO GAVAZZI**

### **Input Specifications**

	RSBD40FV.	RSBD40EV	RSBTEV
Control Voltage Uc, A1-A2 <sup>1</sup>	21.6 - 26.4 VAC/DC	93.5 - 440 VAC	93.5 - 440 VAC
Max. Pick Up Voltage	20.4 VAC/DC	80 VAC	80 VAC
Min. Drop Out Voltage	5 VAC/DC	20 VAC	20 VAC
Rated AC frequency	50/60Hz +/-10%	50/60Hz +/-10%	50/60Hz +/-10%
Rated Insulation Voltage Ui	500 VAC	500 VAC	630 VAC
Dielectric Strength Dielectric withstand voltage Rated Impulse Withstand Voltage	2 kVrms 4 kVrms	2 kVrms 4 kVrms	2 kVrms 4 kVrms
Control Input Current	0.4 1 mAAC	0.5 5 mAAC	36 mAAC
Input to Output response time	< 100 msec*	< 100 msec*	< 100 msec*
Integrated varistor	Yes	Yes	Yes

\* If supply is not already present, when control is applied, Response time is 1500msec

# **Output Specifications**

		RSBD	RSBT
IEC rated operational current le			
(AC-53b) @ 40°C	12 AACrms	RSBD4012.	-
	16 AACrms	RSBD4016	RSBT16
	25 AACrms	RSBD4025	RSBT25
	32 AACrms	RSBD4032	RSBT32
	37 AACrms	RSBD4037	-
	45 AACrms	RSBD4050	-
Overload Cycle		AC53b: 3.5-1:299	16:AC53b:2.5-1:60
acc. to EN/IEC 60947	<b>'-4-2</b>		25:AC53b:3.6-1:60
@ 40°C surrounding t	emperature		32:AC53b:3.4-1:60
Max. Number of start	ts per hour @ 40°C	12	12
Minimum time betwe	en stop and start	1 sec.	60 sec.
Minimum time betwe	en starts	300 sec.	300 sec.
Minimum load curren	nt	1AAC (RSBD4012 RSBD4016)	2AAC
		5AAC (RSBD4025 RSBD4050)	

### **Dimensions**





### Dimensions



# **Environmental Specifications**

#### **Operating Temperature**

eperating rom	o o r a tar o	
	RSBD	-20°C to +60°C (-4°F to +140°F) Note: For operating temp. >40°C derating applies*
RSBT16EV	le<=16 AAC	-20°C to +60°C (-4°F to +140°F)
RSBT25EV	le<=25 AAC	-20°C to +55°C (-4°F to +131°F)
	le<=16 AAC	-20°C to +60°C (-4°F to +140°F)
RSBT32EV	le<=32 AAC	-20°C to +50°C (-4°F to +122°F)
	le<=25 AAC	-20°C to +55°C (-4°F to +131°F)
	le<=16 AAC	-20°C to +60°C (-4°F to +140°F)
Storage Tempe	rature	-40°C to +80°C (-40°F to 176°F)
<b>Relative Humid</b>	ity	<95% non-condensing @ 40°C
Pollution Degre	e	2
Degree of Protection		IP20 (EN/IEC 60529)
Installation Category		Ш
Installation Altitude		1000 m
+		

\* RSBD4012/16/25/37 - 0.8% per °C RSBD4032/50 - 1.2% per °C up to a maximum of 60°C

# **Supply Specifications**

Operational Voltage Range L1 – L3	
RSBD40 RSBT22 RSBT40	187 – 440 VACrms 50/60 Hz 187 – 253 VACrms 50/60 Hz 340 – 440 VACrms 50/60 Hz
Supply Current at standby	<30 mAAC
Blocking voltage RSBD RSBT22EV RSBT40EV	1200 Vp 800Vp 1200Vp
Rated AC frequency	50/60 Hz +/- 10%
Rated insulation voltage RSBD RSBT	500VAC 630VAC
Dielectric strength Dielectric withstand voltage Supply to input Supply to heatsink	2.5 kVms 2.5kVms
Integrated varistor	Yes (across controlled phases)



## **Connection Specifications**

Line conductors L1, L2, L3, T1, T2, T3 Acc. to EN60947-1 flexible	2.5 10 mm <sup>2</sup> 2.5 2 x 4 mm <sup>2</sup>
rigid (solid or stranded) flexible with end sleeve (ferrule)	2.5 10 mm <sup>2</sup>
UL/cUL rated data Rigid (stranded) Rigid (solid) Rigid (solid or stranded)	AWG 614 AWG 1014 AWG 2 x 102 x 14
Terminal screws	6 x M4
Max. tightening torque	2.5 Nm (22 lb.in) with Posidrive bit 2
Max. tightening torque Stripping length	
	Posidrive bit 2
Stripping length Secondary conductors A1, A2 Acc. to EN60998	Posidrive bit 2 8.0 mm 0.5 1.5 mm <sup>2</sup> 0.5 2.5 mm <sup>2</sup>

Terminal screws	9 x M3
Max. tightening torque	0.6Nm (5.3lb.in) with Posidrive bit 0
Stripping length	6.0 mm
Auxiliary conductors	
RSBD: 11, 12, 21 ,24	
rigid (solid or stranded)	0.052.5mm <sup>2</sup>
flexible with end sleeve	
(ferrule)	0.051.5mm <sup>2</sup>
RSBTV2/V6: 11, 12, 14	
rigid (solid or stranded)	0.24mm <sup>2</sup>
flexible with end sleeve	
(ferrule)	0.22.5mm <sup>2</sup>
UL/cUL rated data	
RSBD: 11, 12, 21, 24	11/000 40
rigid (solid or stranded)	AWG3012
RSBTV2/V6: 11, 12, 14	ANN/CO4 10
rigid (solid or stranded)	AWG2412
Terminal screws	
RSBD: 11, 12, 21, 24	M3
RSBTV2/V6: 11, 12, 14	M2.5
Max. tightening torque	
RSBD: 11, 12, 21, 24	0.45 Nm (4.0 lb.in)
RSBT:V2/V6: 11, 12, 14	0.8 Nm (7.0 lb.in)
Stripping length	6 mm

## **Terminal Markings**





## **Wiring Diagram**



Note: Control signal may be applied across any of the three supply lines (L1, L2, L3) as long as the control voltage range is respected.

\* RSBD aux. relay connections: 11,12,21,24 (Alarm and Bypass status indication)
 \* RSBT aux. relay connections: 11,12,14 (Alarm indication only)



Note:

\* RSBD aux. relay connections: 11,12,21,24 (Alarm and Bypass status indication)

\* RSBT aux. relay connections: 11,12,14 (Alarm indication only)

#### **CARLO GAVAZZI**

### **Wiring Diagram**



Note: In case of 24VDC control, apply the 24VDC signal to A1 and the 0V to A2. An incorrect connection may damage the soft starter. \* RSBD aux. relay connections: 11,12,21,24 (Alarm and Bypass status indication) \* RSBT aux. relay connections: 11,12,14 (Alarm indication only)

### **Auxiliary Relays**

Auxiliary relays contact rating	3A, 250 VAC 3A, 30VDC
Bypassed <sup>1</sup> (21,24)	Normally Open (NO)
Alarm RSBD (11,12) RSBTEV2/6 (11, 12, 14)	Normally Closed (NC) Normally Open (NO)/Normally Closed (NC) – Changeover relay contact

## **Housing Specifications**

Weight	
RSBDV51HP RSBDV61HP RSBTV11/V51 RSBTV21/V61	430 g 430 g 425 g 460 g
Material	PA66
Material colour	RAL7035
Terminal colour	RAL7040
Mounting	DIN or Panel

<sup>1</sup> Applies to RSBD models only

# **Electromagnetic Compatibility**

Immunity	IEC/EN 60947-4-2	Rated radio frequency	
Electrostatic discharge (ESD) Immunity	EC/EN 61000-4-2	<b>Immunity</b> 3V/m, 0.15 - 80 MHz	IEC/EN 61000-4-3 Performance Criteria 1
Air discharge: 8kV Contact: 4kV	Performance Criteria 2 Performance Criteria 2	Conducted Radio Frequency Immunity	IEC/EN 61000-4-6
<b>Electrical Fast Transient (Burst)</b>		10V/m, 0.15 - 80 MHz	Performance Criteria 1
Immunity	IEC/EN 61000-4-4	Emission	IEC/EN 60947-4-2
Output: 2kV Input: 1kV	Performance Criteria 2 Performance Criteria 2	Radio interference field emissions (radiated)	
Output, line to line, 1kV Pe Output, line to earth, 2kV Pe Input, line to line, 1kV Pe	IEC/EN 61000-4-5 Performance Criteria 2 Performance Criteria 2	RSBT RSBD	CISPR 11 IEC/EN 55011, Class B CISPR 11 IEC/EN 55011, Class A (Industrial)
	Performance Criteria 2 Performance Criteria 2	Radio interference voltage emissions (conducted)	
		RSBT RSBD	CISPR 11 IEC/EN 55011, Class B CISPR 11 IEC/EN 55011, Class A (Industrial)
		Voltage dips & interruptions 0% Ue & Uc, 5000 ms 40% Ue & Uc, 100/1000 ms 70% Ue & Uc, 10 ms	RSBD/T         RSBTHPV           PC2         PC 3           PC2 / PC2         PC2 / PC3           PC2         PC 2
*Applies to RSBT16EV models only		Harmonics	IEC/EN 61000-3-22

Flicker\*

<sup>1</sup> Applies to RSBD40 models only

<sup>2</sup>Applies to RSBT.. models only

IEC/EN 61000-3-32



## **Agency Approvals and Conformances**

RSBD EN/IEC60947-4-2 UL508 Listed (E172877) cUL Listed (E172877)	<b>RSBT</b> EN/IEC60947-4-2 UL508 Listed (E172877)* cUL Listed (E172877) * VDE (EN60335-1, EN60335-2-40)**/***	

\* Applies to RSBT...EV5.../EV6... versions only

\*\* Applicable up to operational current of 15Arms

\*\*\* Applicable up to operational current of 32Arms (for RSBT..HPV versions only)

## Mode of Operation

#### Auto Adaptive Algorithm (Patented)

RSBD and RSBT series of soft starters includes an innovative auto-adaptive algorithm (Patented) such that an optimum starting current performance is achieved at every compressor start. This feature is active at every compressor start. Appropriate parameters are automatically set by the soft starter in order to achieve an optimum inrush current reduction whilst maintaining a ramp-up time < 1sec.

In case of Locked rotor/ramp-up time alarm, default parameter settings are restored automatically. During the subsequent compressor starts, the auto-adaptive function will start optimising such parameters automatically once again.

#### **RSB....V..HP Specific Mode of Operation**

The RSB....V.HP shall try to start the compressor at the set current limit. Depending on the load requirement, the current limit will be gradually increased up to a maximum of the default current limit, after which the RSB..HP will switch in bypass mode.

If ramping is not achieved after a maximum of 1 second, the Incomplete Ramp alarm (5 flashes on red LED) will be triggered and the RSB....HP will enter into a recovery mode for 5mins. If, at the second consecutive attempt the RSB....HP raises again the Incompete Ramp alarm, then a manual user intervention to reset power on the RSB....HP shall be required, as this might indicate a real locked rotor condition.

#### Auto-adaptive current balancing (applies to RSBD models)

RSBD soft starters use a two-phase control strategy with two anti-parallel thyristors across L1-T1 and L3-T3. Phase L2-T2 is the uncontrolled phase.

During every start, the RSBD soft starter measures a number of parameters and dynamically adjusts the starting parameters to minimise the current unbalance in the phase L2-T2 resulting in a smoother starting performance of the motor.

**Mode of Operation** 



Specifications are subject to change without notice (20.11.2014)

**CARLO GAVAZZI** 



## **Mode of Operation**



\*\* Applies to RSBD40... models only

\*\*\* Applies to RSBD40...V61HP and RSBT..EV2..../EV6.... Models only and when RSBT is used with RSPMV120 accessory

### **CARLO GAVAZZI**

## Alarm LED Indications (Red LED)

		<b>Relay Contact Position</b>				
Flashes	Description of Fault	RSBD (11, 12)	RSBT	RSBTHP.	Action	
2	Wrong Phase Sequence	Open	11/12	11/12	Physical Change	
3	Line Voltage Out of Range	Open	11/12	11/12	Auto reset with 5mins recovery	
4	Frequency Out of Range	Open	11/12	11/12	Auto reset with 5mins recovery	
5	Over Current (during RAMPING)	Open	11/12	11/12	Auto reset with 5mins recovery	
6	Ramp Up Time > 1 sec	Open	11/12	11/12	Auto reset with 5mins recovery	
7	Over Temperature	Open	11/12	11/12	Auto reset with 5mins recovery	
8	Over Current (during BYPASS)	Open	11/12	11/12	Auto reset with 5mins recovery	
9	Supply Voltage Unbalance	Open	11/12	11/12	Auto reset with 5mins recovery assuming all phases (L1, L2, L3) are connected	
Fully ON (Green LED OFF)	Special (Internal) alarm	N/A	N/A	11/12	Reset power (L1-L3). If fault is not cleared upon reset, please contact your CG representative.	

## **LED Status Indications (Green LED)**

Status	Condition	Relay Contact Position				A .::
		RSBD (11, 12)	RSBD (21, 24)	RSBT	RSBTHP	- Action
Flashing	Recovery time between starts	Closed	Open	11/14	11/14	N/A
Fully ON	Idle State	Closed	Open	11/14	11/14	N/A
Fully ON	Ramping	Closed	Open	11/12	11/14	N/A
Fully ON	Bypassed	Closed	Closed	11/14	11/14	N/A

### **Flashing Sequence**

#### Alarm Condition



Note: For RSBT...HPV models - if a safety-related alarm is triggered in bypass mode, the RSBT will keep the load/output ON. It is up to the system controller/ safety device to switch OFF the load.

# **Short Circuit Protection**

#### Protection Co-ordination, Type 1 vs Type 2

Type 1 protection implies that after a short circuit, the device under test will no longer be in a functioning state.

In Type 2 co-ordination the device under test will still be functional after the short circuit. In both cases, however the short circuit has to be interrupted. The fuse between enclosure and supply shall not open. The door or cover of the enclosure shall not be blown open. There shall be no damage to conductors or terminals and the conductors shall not separate from terminals. There shall be no breakage or cracking of insulating bases to the extent that the integrity of the mounting of live parts is impaired. Discharge of parts or any risk of fire shall not occur.

The product variants listed in the table hereunder are suitable for use on a circuit capable of delivering not more than 5,000A rms Symmetrical Amperes,400 Volts maximum when protected by fuses. Tests at 5,000A were performed with Class RK5 fuses, fast acting; please refer to the table below for maximum allowed ampere rating of the fuse. Use fuses only.

Products rated 12A and 16A, protected with manual motor starters must be wired with a minimum length of 15m of Cu wire conductor with a minimum cross sectional area of 2.5mm<sup>2</sup>. Products rated 25A or higher, protected with manual motor starters must be wired with a minimum length of 10m of Cu wire conductor.\*

\*The length includes the conductors from the voltage source to the manual manual starter, from the manual motor starter to the soft starter and from the soft starter to the load.

Co-ordination Type	· · ·			
Part. No.	Max. Fuse Size [A]	Class	Current [kA]	Max. Voltage [VAC]
RSBD4012.V	20	RK5	5	400
RSBD4016.V	20	RK5	5	400
RSBD4025.V	25	RK5	5	400
RSBD4032.V	35	RK5	5	400
RSBD4037.V	50	RK5	5	400
RSBD4050.V	50	RK5	5	400
Co-ordination Type	1 Manual Motor Starters -	RSBD		
	Model No.		Current [kA]	Max. Voltage [VAC]
RSBD4012.V	GMS32S-17	GMS32S-17/GMS32H-17		400
RSBD4016.V	GMS32S-17	7/GMS32H-17	10	400
RSBD4025.V	GMS	32H-32	10	400
RSBD4032.V	GMS	32H-32	10	400
RSBD4037.V	GMS63S-50	GMS63S-50 / GMS63H-50		400
RSBD4050.V	GMS63S-50	)/GMS63H-50	10	400
Co-ordination Type	1 (UL508) - RSBT			
Part. No.	Max. Size [A]	Class	Current [kA]	Max. Voltage [VAC]
RSBT16EV5	40	RK5	5	400
RSBT16EV6	40	11105	5	400
RSBT25EV5 RSBT25EV6	40	RK5	5	400
RSBT32EV5				
RSBT32EV6	40	RK5	5	400
Co-ordination Type	2 (IEC/EN 60947-4-2) – RS	BD		
	Max. Size [A]	Class	Current [kA]	Max. Voltage [VAC]
RSBD4012.V	35	A70 QS 35-4	5	400
RSBD4016.V	35	A70 QS 35-4	5	400
RSBD4025.V	50 / 63	A70 QS 60-4 / 6.9xx CP URD 22 x 58/63 (xx = 00 or 21)	5	400
RSBD4032.V	60	A70 QS 60-4	5	400
RSBD4037.V,	125	A70 QS 125-4	5	400
RSBD4050.V	125	A70 QS 125-4	5	400
Co-ordination Type	2 (IEC/EN 60947-4-2) - RS	BT		1
	Ferraz Shawmut/ MERSEN		Current [kA]	Max. Voltage [VAC]
	Max. Size [A]	Part Number	5	400
RSBT16EV	50	6.9xx CP gRC 14.51 50 (xx = 00 or 231)	5	400
RSBT25EV	50	6.9xx CP gRC 14.51 50 (xx = 00 or 21)	5	400
RSBT32EV	50	6.9xx CP gRC 14.51 50 (xx = 00 or 21)	5	400

**CARLO GAVAZZI** 



### **Current / Power Ratings**

Current / Power Ratings - RSBD							
Assigned compressor rating @ 40°C UL rating @ 40°C	220V	400V	Max. Current limit level Irms				
RSBD4012.V	3 kW (3 HP)	5.5 kW (5 HP)	42 Arms				
RSBD4016.V	4 kW (5 HP)	7.5 kW (7.5 HP)	56 Arms				
RSBD4025.V	5.5 kW (7.5 HP)	11 kW (10 HP)	87.5 Arms				
RSBD4032.V	9 kW (10 HP)	15 kW (15 HP)	112 Arms				
RSBD4037.V	9 kW (10 HP)	18.5 kW (20 HP)	129.5 Arms				
RSBD4050.V	11 kW (15 HP)	22 kW (25 HP)	175 Arms				
Current / Power Ratings - RSBT							
Assigned compressor rating @ 40°C UL rating @ 40°C	220V	400V	Max. Current limit level Irms				
RSBT2216EV	4.0 kW (5.0 HP)	-	40 Arms				
RSBT2225EV	5.5 kW (7.5 HP)	-	90 Arms				
RSBT2232EV	9.0 kW (10.0 HP)	-	110 Arms				
RSBT4016EV	-	7.5 kW (7.5 HP)	40 Arms				
RSBT4025EV	-	11.0 kW (10.0 HP)	90 Arms				
RSBT4032EV	-	15.0 kW (15.0 HP)	110 Arms				

Note: Motor kW ratings are provided as a reference. User shall always ensure that compressor operational current and overload current of the compressor during starting does not exceed the rating of the softstarter being used.

### Accessories

### **Auxiliary Output Module**



### **Auxiliary Relay Alarm Output**



- 17.5mm DIN rail housing
- LED indication for supply ON
- Plug'n'play design
- Output (1):100mA, Open collector, Normally Open (NO) Output (2): 3A SPDT relay \*
- RoHs compliant
- Ordering code: RSPMV110 (1-output) / RSPMV120 (2-output)
- CE, cULus (Accessory of listed RSBT)

\* Only applicable to RSPMV120

- Normally open (NO) or Normally Closed (NC) configuration
- Contact rating: 3A, 250 VAC / 3A, 30VDC
- 1-Relay Output for alarms generated by softstarter
- Ordering code: RFPMV00
- UL, cUL Listed (Accessory of Listed RSBT)

### Accessories



### **EMC/ RFI Filter**



### **RTPM (Interconnecting Clip)**



### **GMS (Manual Motor Starter)**

- Insertion loss 5dB
- Lightweight and compact design
- Operational current: Max. 32A @ 60°C
- $\bullet$  Rated operational voltage: 220/ 440 VAC  $\pm$  15%
- Ordering code: RFILT4032V00
- UL, cUL Listed (Accessory of Listed RSBT)

# Ordering Key

Interconnecting clip for GMS-32-H motor starter

**RTPMGMS32HL** 

• Qty: 10pcs per bag

Interconnecting clip for GMS-32-S motor starter

**RTPMGMS32SL** 

Qty: 10pcs per bag



### Accessories

#### **GMS Mounting Instructions**



The following procedure should be followed when mounting the GMS motor starter onto the RSB. soft starter:- **Step 1:** Unscrew the terminals on the RSB. and GMS units and insert the proper RTPM clip in the respective terminals. **Step 2:** Tighten the screws on the GMS and RSB. units respecting the maximum torque specified. **Step 3:** Mount the complete assembly to the DIN rail and screw the RSB. to the panel as shown in the diagram.

Note: Always mount the GMS motor starter on the supply side (L1, L2, L3) of the RSB. soft starter. Important: Make sure that the handle on the GMS starter is in the OFF position before installing and uninstalling. **CARLO GAVAZZI**